

# Teensy<sup>®</sup> 4.1 Features

For use of Ethernet, USB Host,  
memory chips, and alternate pin functions,  
please refer to the website for the latest info.

[www.pjrc.com/store/teensy41.html](http://www.pjrc.com/store/teensy41.html)

Cut to separate VIN from VUSB, if using  
a battery charger or external power.

Teensy 4.1 pins are  
**not 5 volt tolerant.**  
Do not apply more  
than 3.3 volts.

For solutions to the most common issues  
and technical support, please visit:

[www.pjrc.com/help](http://www.pjrc.com/help)

Teensy 4.1 System Requirements:  
PC computer with Windows 7, 8, 10 or later  
or Ubuntu Linux 14.04 or later  
or Macintosh MacOS 10.10 or later  
USB Micro-B Cable

